

SV9000 AF DRIVES
SVReady™ User Manual

Multi-Step Speed Control Application



Cutler-Hammer

EATON

A General

This manual provides you with the information needed to apply these applications.

Each application is described in its own chapter. Section B tells how to select the application.

B Application selection

If the Basic Application is in use, first open the application package lock (parameter 1.15 = 0) Group 0 appears. By changing the value of parameter 0.1 a different application can be selected. See table B-1.

To change from one application to another, simply change the value of parameter 0.1 to that of the application desired: see table B-1.

Number	Parameter	Range	Description
0. 1	Application	1 —7	1 = Basic Application 2 = Standard Application 3 = Local / Remote Control Application 4 = Multi-step Speed Application 5 = PI-control Application 6 = Multi-purpose Control Application 7 = Pump and Fan Control Application

Table B-1 Application selection parameters.

Besides the parameter group 1, the applications also have parameter groups 2 — 8 available (see figure B-1).

Parameters of the groups sequentially follow each other and changing from the last parameter of one group to the first parameter of the next group or vice versa is done simply by pushing the arrow up/arrow down buttons.




Figure B-1 Parameter Groups.

C Restoring default values of application parameters

Default values of the parameters of the applications 1 to 7 can be restored by selecting the same application again with parameter 0.1 or by setting the value of parameter 0.2 to 1. See User's manual chapter 12.

If parameter group 0 is not visible, make it visible as follows:

1. If parameter lock is set on, open the lock, parameter 1. 16, by setting the value of the parameter to 0.
2. If parameter conceal is set on, open the conceal parameter 1. 15, by setting the value of the parameter to 0.
Group 0 becomes visible.

D Language selection

The language of the text shown on the operator's panel can be chosen with parameter 0. 3. See SV9000 User's Manual, chapter 11.



MULTI-STEP SPEED CONTROL APPLICATION
(par. 0.1 = 4)

CONTENTS

3 Multi-step Speed Control Appl. 3-1

3.1 General 3-2

3.2 Control I/O 3-2

3.3 Control signal logic 3-3

3.4 Parameters Group 1 3-4

3.4.1 Parameter table 3-4

3.4.2 Description of Group1 par ... 3-5

3.5 Special parameters, Groups 2—8 .. 3-8

3.5.1 Parameter tables 3-8

3.5.2 Description of Groups. 3-14



3.1 GENERAL

The Multi-step Speed Control Application can be used in applications where fixed speeds are needed. In total 9 different speeds can be programmed: one basic speed, 7 multi-step speeds and one jog speed. The speed steps are selected with digital signals DIB4, DIB5 and DIB6. If jog speed is used, DIA3 can be

programmed from fault reset to jog speed select.

The basic speed reference can be either a voltage or a current signal via analog input terminals (2/3 or 4/5). The other analog input can be programmed for other purposes

All outputs are freely programmable.

*** NOTE!** Remember to connect the CMA and CMB inputs.

3.2 CONTROL I/O

Reference potentiometer 1 - 10 k Ω




Figure 3.2-1 Default I/O configuration and connection example of the Multi-step speed Control Application.



3.3 Control signal logic













Figure 3.3-1 Control signal logic of the Multi-step Speed Control Application.
Switch positions shown are based on the factory settings.

3.4 Basic parameters, Group 1

Code	Parameter	Range	Step	Default	Custom	Description	Page
1. 1	Minimum frequency	0— f_{\max}	1 Hz	0 Hz			3-5
1. 2	Maximum frequency	f_{\min} —120/500Hz	1 Hz	60 Hz		*	3-5
1. 3	Acceleration time 1	0.1—3000.0 s	0.1 s	3.0 s		Time from f_{\min} (1. 1) to f_{\max} (1. 2)	3-5
1. 4	Deceleration time 1	0.1—3000.0 s	0.1 s	3.0 s		Time from f_{\max} (1. 2) to f_{\min} (1. 1)	3-5
1. 5	Basic reference selection 	0—1	1	0		0 = Analog voltage input (term.2) 1 = Analog current input (term.4)	3-5
1. 6	Jog speed reference	f_{\min} — f_{\max} (1. 1) (1. 2)	0.1 Hz	5.0 Hz			3-5
1. 7	Current limit	0.1—2.5 x $I_{n\text{ SV9}}$	0.1 A	1.5 x $I_{n\text{ SV9}}$		Output current limit [A] of the unit	3-5
1. 8	V/Hz ratio selection 	0—2	1	0		0 = Linear 1 = Squared 2 = Programmable V/Hz ratio	3-6
1. 9	V/Hz optimisation 	0—1	1	0		0 = None 1 = Automatic torque boost	3-7
1. 10	Nominal voltage of the motor 	180—690 V	1 V	230 V 380 V 480 V 575 V		Voltage code 2 Voltage code 4 Voltage code 5 Voltage code 6	3-7
1. 11	Nominal frequency of the motor 	30—500 Hz	1 Hz	60 Hz		f_n from the nameplate of the motor	3-7
1. 12	Nominal speed of the motor 	1—20000 rpm	1 rpm	1720 rpm **		n_n from the nameplate of the motor	3-7
1. 13	Nominal current of the motor 	2.5 x $I_{n\text{ SV9}}$	0,1 A	$I_{n\text{ SV9}}$		I_n from the nameplate of the motor	3-7
1. 14	Supply voltage 	208—240		230 V		Voltage code 2	3-7
		380—440		380 V		Voltage code 4	
		380—500		480 V		Voltage code 5	
		525—690		575 V		Voltage code 6	
1. 15	Parameter conceal	0—1	1	0		Visibility of the parameters: 0 = all parameter groups visible 1 = only group 1 is visible	3-7
1. 16	Parameter value lock	0—1	1	0		Disables parameter changes: 0 = changes enabled 1 = changes disabled	3-7

Note!  = Parameter value can be changed only when the frequency converter is stopped.

* If 1. 2 > motor synchr. speed, check suitability for motor and drive system
Selecting 120/500 Hz range see page 3-5.

** Default value for a four pole motor and a nominal size SV9000.



Code	Parameter	Range	Step	Default	Custom	Description	Page
1. 17	Multi-step speed reference 1	f_{\min} — f_{\max} (1. 1) (1. 2)	0.1 Hz	10.0 Hz			3-7
1. 18	Multi-step speed reference 2	f_{\min} — f_{\max} (1. 1) (1. 2)	0.1 Hz	15.0 Hz			3-7
1. 19	Multi-step speed reference 3	f_{\min} — f_{\max} (1. 1) (1. 2)	0.1 Hz	20.0 Hz			3-7
1. 20	Multi-step speed reference 4	f_{\min} — f_{\max} (1. 1) (1. 2)	0.1 Hz	25.0 Hz			3-7
1. 21	Multi-step speed reference 5	f_{\min} — f_{\max} (1. 1) (1. 2)	0.1 Hz	30.0 Hz			3-7
1. 22	Multi-step speed reference 6	f_{\min} — f_{\max} (1. 1) (1. 2)	0.1 Hz	40.0 Hz			3-7
1. 23	Multi-step speed reference 7	f_{\min} — f_{\max} (1. 1) (1. 2)	0.1 Hz	50.0 Hz			3-7

Table 3.4-1 Group 1 basic parameters.

3.4.2 Description of Group 1 parameters

1. 1, 1. 2 Minimum/maximum frequency

Defines the frequency limits of the SV9000.

The default maximum value for parameters 1. 1 and 1. 2 is 120 Hz. By setting 1. 2 = 120 Hz in the when the drive is stopped (RUN indicator not lit) parameters 1. 1 and 1. 2 are changed to 500 Hz. At the same time the resolution of the panel reference is changed from 0.01 Hz to 0.1 Hz.

Changing the max. value from 500 Hz to 120 Hz is done by setting parameter 1. 2 to 119 Hz while the drive is stopped.

1. 3, 1. 4 Acceleration time 1, deceleration time 1:

These limits correspond to the time required for the output frequency to accelerate from the set minimum frequency (par. 1. 1) to the set maximum frequency (par. 1. 2). Acceleration/deceleration times can be reduced with a free analog input signal, see parameters 2. 18 and 2. 19.

1. 5 Basic reference selection

- 0: Analog voltage reference from terminals 2—3, e.g. a potentiometer
- 1: Analog current reference from terminals 4—5, e.g. a transducer

1. 6 Jog speed reference

The value of this parameter defines the jog speed selected with the DIA3 digital input which if it is programmed for Jog speed. See parameter 2. 2.

Parameter value is automatically limited between minimum and maximum frequency (par 1. 1, 1. 2)

1. 7 Current limit

This parameter determines the maximum motor current that the SV9000 will provide short term. Current limit can be set lower with a free analog input signal, see parameters 2. 18 and 2. 19.



1.8 V/Hz ratio selection

Linear: The voltage of the motor changes linearly with the frequency in the constant flux area from 0 Hz to the field weakening point (par. 6. 3) where a constant voltage (nominal value) is supplied to the motor. See figure 3.4-1.

0

A linear V/Hz ratio should be used in constant torque applications

This default setting should be used if there is no special requirement for another setting.

Squared: The voltage of the motor changes following a squared curve form with the frequency in the area from 0 Hz to the field weakening point (par. 6. 3), where the nominal voltage is supplied to the motor. See figure 3.4-1.

1

The motor runs undermagnetized below the field weakening point and produces less torque and electromechanical noise. A squared V/Hz ratio can be used in applications where the torque demand of the load is proportional to the square of the speed, e.g. in centrifugal fans and pumps.




Figure 3.4-1 Linear and squared V/Hz curves.

Programm. The V/Hz curve can be programmed with three different points.

V/Hz curve The parameters for programming are explained in chapter 3.5.2.

2

A programmable V/Hz curve can be used if the standard settings do not satisfy the needs of the application. See figure 3.4-2.




Figure 3.4-2 Programmable V/Hz curve.

1. 9 V/Hz optimization

Automatic torque boost The voltage to the motor changes automatically which allows the motor to produce enough torque to start and run at low frequencies. The voltage increase depends on the motor type and horsepower. Automatic torque boost can be used in applications where starting torque due to starting friction is high, e.g. in conveyors.

NOTE! *In high torque - low speed applications - it is likely the motor will overheat.*



If the motor has to run for a prolonged time under these conditions, special attention must be paid to cooling the motor. Use external cooling for the motor if the temperature rise is too high.

1. 10 Nominal voltage of the motor

Find this value V_n from the nameplate of the motor.
This parameter sets the voltage at the field weakening point, parameter 6. 4, to $100\% \times V_{n\text{motor}}$.

1. 11 Nominal frequency of the motor

Find then nominal frequency f_n from the nameplate of the motor.
This parameter sets the field weakening point, parameter 6. 3, to the same value.

1. 12 Nominal speed of the motor

Find this value n_n from the nameplate of the motor.

1. 13 Nominal current of the motor

Find the value I_n from the nameplate of the motor.
The internal motor protection function uses this value as a reference value.

1. 14 Supply voltage

Set parameter value according to the nominal voltage of the supply.
Values are pre-defined for voltage codes 2, 4, 5, and 6. See table 3.4-1.

1. 15 Parameter conceal

Defines which parameter groups are available:

- 0 = all parameter groups are visible
- 1 = only group 1 is visible

1. 16 Parameter value lock

Defines access to the changes of the parameter values:

- 0 = parameter value changes enabled
- 1 = parameter value changes disabled



1. 17 - 1. 23 Multi-step speed reference 1—7

These parameter values define the Multi-step speeds selected with the DIA4, DIB5 and DIB6 digital inputs .

These values are automatically limited between minimum and maximum frequency (par. 1. 1, 1. 2).



Speed reference	Multi-step speed select 1 DIB4	Multi-step speed select 2 DIB5	Multi-step speed select 3 DIB6
Par. 1. 6	0	0	0
Par. 1. 17	1	0	0
Par. 1. 18	0	1	0
Par. 1. 19	1	1	0
Par. 1. 20	0	0	1
Par. 1. 21	1	0	1
Par. 1. 22	0	1	1
Par. 1. 23	1	1	1


Table 3.4-2 Selection of multi-step speed reference 1—7.

3.5 Special parameters, Groups 2—8

3.5.1 Parameter tables





Input signal parameters, Group 2


Code	Parameter	Range	Step	Default	Custom	Description	Page
2. 1	Start/Stop logic selection 	0—3	1	0		DIA1	3-15
						DIA2	
						0 = Start forward 1 = Start/Stop 2 = Start/Stop 3 = Start pulse	
						Start reverse Reverse Run enable Stop pulse	
2. 2	DIA3 function (terminal 10) 	0—9	1	7		0 = Not used 1 = Ext. fault, closing contact 2 = External fault, opening contact 3 = Run enable 4 = Acc./Dec. time selection 5 = Reverse (if par. 2. 1 = 3) 6 = Jog speed 7 = Fault reset 8 = Acc./Dec. operation prohibit 9 = DC-braking command	3-16
2. 3	V _{in} signal range	0—1	1	0		0 = 0 — 10 V 1 = Custom setting range	3-17
2. 4	V _{in} custom setting min.	0.00-100.00%	0.01%	0.00%			3-17
2. 5	V _{in} custom setting max.	0.00-100.00%	0.01%	100.00%			3-17
2. 6	V _{in} signal inversion	0—1	1	0		0 = Not inverted 1 = Inverted	3-18
2. 7	V _{in} signal filter time	0.00 — 10.0 s	0.01s	0.10 s		0 = No filtering	3-18
2. 8	I _{in} signal range	0—2	1	0		0 = 0—20 mA 1 = 4—20 mA 2 = Custom setting range	3-19
2. 9	I _{in} custom setting minim.	0.00-100.00%	0.01%	0.00%			3-19
2. 10	I _{in} custom setting maxim.	0.00-100.00%	0.01%	100.00%			3-19
2. 11	I _{in} signal inversion	0—1	1	0		0 = Not inverted 1 = Inverted	3-19
2. 12	I _{in} signal filter time	0.01 — 10.00s	0.01s	0.10 s		0 = No filtering	3-19
2. 13	Reference scaling minimum value	0— par. 2. 14	1 Hz	0 Hz		Selects the frequency that corresponds to the min. reference signal	3-20
2. 14	Reference scaling maximum value	0— f _{max} (1. 2)	1 Hz	0 Hz		Selects the frequency that corresponds to the max. reference signal 0 = Scaling off >0 = Scaled maximum value	3-20
2. 15	Free analog input, signal selection	0—2	1	0		0 = Not use 1 = V _{in} (analog voltage input) 2 = I _{in} (analog current input)	3-20
2. 16	Free analog input, function	0—4	1	0		0 = No function 1 = Reduces current limit (par. 1.7) 2 = Reduces DC-braking current 3 = Reduces acc. and decel. times 4 = Reduces torque supervision limit	3-20

Note!  = Parameter value can be changed only when the drive is stopped.




Group 3, Output and supervision parameters


Code	Parameter	Range	Step	Default	Custom	Description	Page
3. 1	Analog output function 	0—7	1	1		0 = Not used Scale 100% 1 = O/P frequency (0— f_{\max}) 2 = Motor speed (0—max. speed) 3 = O/P current (0— $2.0 \times I_{nSV9}$) 4 = Motor torque (0— $2 \times T_{nMot}$) 5 = Motor power (0— $2 \times P_{nMot}$) 6 = Motor voltage (0— $100\% \times V_{nMot}$) 7 = DC-link volt. (0—1000 V)	3-22
3. 2	Analog output filter time	0.00—10.00 s	0.01 s	1.00 s			3-22
3. 3	Analog output inversion	0—1	1	0		0 = Not inverted 1 = Inverted	3-22
3. 4	Analog output minimum	0—1	1	0		0 = 0 mA 1 = 4 mA	3-22
3. 5	Analog output scale	10—1000%	1%	100%			3-22
3. 6	Digital output function 	0—21	1	1		0 = Not used 1 = Ready 2 = Run 3 = Fault 4 = Fault inverted 5 = SV9000 overheat warning 6 = External fault or warning 7 = Reference fault or warning 8 = Warning 9 = Reversed 10 = Jog speed selected 11 = At speed 12 = Motor regulator activated 13 = Output frequency limit superv. 1 14 = Output frequency limit superv. 2 15 = Torque limit supervision 16 = Reference limit supervision 17 = External brake control 18 = Control from I/O-terminals 19 = Drive temperature limit supervision 20 = Unrequested rotation direction 21 = External brake control inverted	3-23
3. 7	Relay output 1 function 	0—21	1	2		As parameter 3. 6	3-23
3. 8	Relay output 2 function 	0—21	1	3		As parameter 3. 6	3-23
3. 9	Output freq. limit 1 supervision function	0—2	1	0		0 = No 1 = Low limit 2 = High limit	3-23
3. 10	Output freq. limit 1 supervision value	0.0— f_{\max} (par. 1. 2)	0.1 Hz	0.0 Hz			3-23


Note!  = Parameter value can be changed only when the drive is stopped.



Code	Parameter	Range	Step	Default	Custom	Description	Page
3. 11	Output freq. limit 2 supervision function	0—2	1	0		0 = No 1 = Low limit 2 = High limit	3-23
3. 12	Output freq. limit 2 supervision value	0.0— f_{\max} (par. 1. 2)	0.1 Hz	0.0 Hz			3-23
3. 13	Torque limit supervision function	0—2	1	0		0 = No 1 = Low limit 2 = High limit	3-24
3. 14	Torque limit supervision value	0.0—200.0 % $\times T_{nSV9}$	0.1%	100.0%			3-24
3. 15	Reference limit supervision function	0—2	1	0		0 = No 1 = Low limit 2 = High limit	3-24
3. 16	Reference limit supervision value	0.0— f_{\max} (par. 1. 2)	0.1 Hz	0.0 Hz			3-24
3. 17	Extern. brake Off-delay	0.0—100.0 s	0.1 s	0.5 s			3-24
3. 18	Extern. brake On-delay	0.0—100.0 s	0.1 s	1.5 s			3-24
3. 19	Drive temperature limit supervision	0—2	1	0		0 = No 1 = Low limit 2 = High limit	3-25
3. 20	Drive temperature limit value	-10—+75°C	1	40°C			3-25
3. 21	I/O-expander board (opt.) analog output function 	0—7	1	3		See parameter 3. 1	3-22
3. 22	I/O-expander board (opt.) analog output filter time	0.00—10.00 s	0.01 s	1.00 s		See parameter 3. 2	3-22
3. 23	I/O-expander board (opt.) analog output inversion	0—1	1	0		See parameter 3. 3	3-22
3. 24	I/O-expander board (opt.) analog output minimum	0—1	1	0		See parameter 3. 4	3-22
3. 25	I/O-expander board (opt.) analog output scale	10—1000%	1	100%		See parameter 3. 5	3-22

Group 4, Drive control parameters

Code	Parameter	Range	Step	Default	Custom	Description	Page
4. 1	Acc./Dec. ramp 1 shape	0.0—10.0 s	0.1 s	0.0 s		0 = Linear >0 = S-curve acc./dec. time	3-25
4. 2	Acc./Dec. ramp 2 shape	0.0—10.0 s	0.1 s	0.0 s		0 = Linear >0 = S-curve acc./dec. time	3-25
4. 3	Acceleration time 2	0.1—3000.0s	0.1 s	10.0 s			3-25
4. 4	Deceleration time 2	0.1—3000.0s	0.1 s	10.0 s			3-25
4. 5	Brake chopper 	0—2	1	0		0 = Brake chopper not in use 1 = Brake chopper in use 2 = External brake chopper	3-26
4. 6	Start function	0—1	1	0		0 = Ramp 1 = Flying start	3-26

Note!  = Parameter value can be changed only when the drive is stopped.










Code	Parameter	Range	Step	Default	Custom	Description	Page
4.7	Stop function	0—1	1	0		0 = Coasting 1 = Ramp	3-26
4.8	DC-braking current	0.15—1.5 x I_{nSVg} (A)	0.1 A	0.5 x I_{nSVg}			3-26
4.9	DC-braking time at Stop	0.00—250.00s	0.01 s	0.00 s		0 = DC-brake is off at Stop	3-26
4.10	Turn on frequency of DC brake during ramp Stop	0.1—10.0 Hz	0.1 Hz	1.5 Hz			3-28
4.11	DC-brake time at Start	0.00—25.00 s	0.01 s	0.00 s		0 = DC-brake is off at Start	3-28

Group 5, Prohibit frequency parameters

Code	Parameter	Range	Step	Default	Custom	Description	Page
5.1	Prohibit frequency range 1 low limit	f_{min} — par. 5.2	0.1 Hz	0.0 Hz			3-28
5.2	Prohibit frequency range 1 high limit	f_{min} — f_{max} (1.1) (1.2)	0.1 Hz	0.0 Hz		0 = Prohibit range 1 is off	3-28
5.3	Prohibit frequency range 2 low limit	f_{min} — par. 5.4	0.1 Hz	0.0 Hz			3-28
5.4	Prohibit frequency range 2 high limit	f_{min} — f_{max} (1.1) (1.2)	0.1 Hz	0.0 Hz		0 = Prohibit range 2 is off	3-28
5.5	Prohibit frequency range 3 low limit	f_{min} — par. 5.6	0.1 Hz	0.0 Hz			3-28
5.6	Prohibit frequency range 3 high limit	f_{min} — f_{max} (1.1) (1.2)	0.1 Hz	0.0 Hz		0 = Prohibit range 3 is of	3-28

Group 6, Motor control parameters

Code	Parameter	Range	Step	Default	Custom	Description	Page
6.1	Motor control mode 	0—1	1	0		0 = Frequency control 1 = Speed control	3-29
6.2	Switching frequency	1.0—16.0 kHz	0.1 kHz	10/3.6 kHz		Dependant on Hp rating	3-29
6.3	Field weakening point 	30—500 Hz	1 Hz	Param. 1.11			3-29
6.4	Voltage at field weakening point 	15—200% x V_{nmot}	1%	100%			3-29
6.5	V/Hz curve, midpoint frequency 	0.0— f_{max}	0.1 Hz	0.0 Hz			3-29
6.6	V/Hz-curve, midpoint voltage 	0.00—100.00% x V_{nmot}	0.01%	0.00%			3-29
6.7	Output voltage at zero frequency 	0.00—100.00% x V_{nmot}	0.01%	0.00%			3-29
6.8	Overvoltage controller	0—1	1	1		0 = Controller is turned off 1 = Controller is operating	3-30
6.9	Undervoltage controller	0—1	1	1		0 = Controller is turned off 1 = Controller is operating	3-30

Note!  = Parameter value can be changed only when the drive is stopped.



Group 7, Protections

Code	Parameter	Range	Step	Default	Custom	Description	Page
7.1	Response to reference fault	0—3	1	0		0 = No action 1 = Warning 2 = Fault, stop according to par. 4.7 3 = Fault, always coasting stop	3-30
7.2	Response to external fault	0—3	1	2		0 = No action 1 = Warning 2 = Fault, stop according to par. 4.7 3 = Fault, always coasting stop	3-30
7.3	Phase supervision of the motor	0—2	2	2		0 = No action 2 = Fault	3-30
7.4	Ground fault protection	0—2	2	2		0 = No action 2 = Fault	3-31
7.5	Motor thermal protection	0—2	1	2		0 = No action 1 = Warning 2 = Fault	3-31
7.6	Motor thermal protection break point current	50.0—150.0 % $\times I_{nMOTOR}$	1.0 %	100.0%			3-32
7.7	Motor thermal protection zero frequency current	5.0—150.0% $\times I_{nMOTOR}$	1.0 %	45.0%			3-32
7.8	Motor thermal protection time constant	0.5—300.0 minutes	0.5 min.	17.0 min.		Default value is set according to motor nominal current	3-33
7.9	Motor thermal protection break point frequency	10—500 Hz	1 Hz	35 Hz			3-33
7.10	Stall protection	0—2	1	1		0 = No action 1 = Warning 2 = Fault	3-34
7.11	Stall current limit	5.0—200.0% $\times I_{nMOTOR}$	1.0%	130.0%			3-34
7.12	Stall time	2.0—120.0 s	1.0 s	15.0 s			3-34
7.13	Maximum stall frequency	1— f_{max}	1 Hz	25 Hz			3-34
7.14	Underload protection	0—2	1	0		0 = No action 1 = Warning 2 = Fault	3-35
7.15	Underload prot., field weakening area load	10.0—150.0 % $\times T_{nMOTOR}$	1.0%	50.0%			3-35
7.16	Underload protection, zero frequency load	5.0—150.0% $\times T_{nMOTOR}$	1.0%	10.0%			3-35
7.17	Underload time	2.0—600.0 s	1.0 s	20.0s			3-36



Group 8, Autorestart parameters

Code	Parameter	Range	Step	Default	Custom	Description	Page
8.1	Automatic restart: number of tries	0—10	1	0		0 = not in use	3-36
8.2	Automatic restart: multi attempt maximum trial time	1—6000 s	1 s	30 s			3-36
8.3	Automatic restart: start function	0—1	1	0		0 = Ramp 1 = Flying start	3-37
8.4	Automatic restart after undervoltage trip	0—1	1	0		0 = No 1 = Yes	3-37
8.5	Automatic restart after overvoltage trip	0—1	1	0		0 = No 1 = Yes	3-37
8.6	Automatic restart after overcurrent trip	0—1	1	0		0 = No 1 = Yes	3-37
8.7	Automatic restart after reference fault trip	0—1	1	0		0 = No 1 = Yes	3-37
8.8	Automatic restart after over/undertemperature fault trip	0—1	1	0		0 = No 1 = Yes	3-37

Table 3.5-1 Special parameters, Groups 2—8.



3.5.2 Description of Groups 2—8 parameters

2.1 Start/Stop logic selection

- 0: DIA1: closed contact = start forward
 DIA2: closed contact = start reverse,
 See figure 3.5-1.




Figure 3.5-1 Start forward/Start reverse.

- ① The first selected direction has the highest priority
- ② When DIA1 contact opens, the direction of rotation starts to change
- ③ If Start forward (DIA1) and start reverse (DIA2) signals are active simultaneously, the start forward signal (DIA1) has priority.

- 1: DIA1: closed contact = start open contact = stop
 DIA2: closed contact = reverse open contact = forward
 See figure 3.5-2.




Figure 3.5-2 Start, Stop, reverse.



- 2: DIA1: closed contact = start open contact = stop
 DIA2: closed contact = start enabled open contact = start disabled
- 3: 3-wire connection
 DIA1: closed contact = start pulse
 DIA2: closed contact = stop pulse
 (DIA3 can be programmed for reverse command)
 See figure 3.5-3.




Figure 3.5-3 Start pulse /Stop pulse.

2. 2 DIA3 function

- 1: External fault, closing contact = Fault is shown and drive responds according to parameter 7.2.
- 2: External fault, opening contact = Fault is shown and drive responds according to parameter 7.2.
- 3: Run enable contact open = Start of the motor disabled
 contact closed = Start of the motor enabled
- 4: Acc. / Dec time select. contact open = Acceleration/Deceleration time 1 selected
 contact closed = Acceleration/Deceleration time 2 selected
- 5: Reverse contact open = Forward || Can be used for reversing if
 contact closed = Reverse || parameter 2. 1 has value 3
- 6: Jog speed contact closed = Jog speed selected for freq. refer.
- 7: Fault reset contact closed = Resets all faults
- 8: Acc./Dec. operation prohibited
 contact closed = Stops acceleration or deceleration until the contact is opened
- 9: DC-braking command
 contact closed = In Stop mode, the DC-braking operates until the contact is opened, see figure 3.5-4. DC-brake current is set with parameter 4. 8.






Figure 3.5-4 DIA3 as DC-brake command input: a) Stop mode = Ramp, b) Stop mode = Coasting.

2.3 V_{in} signal range

0 = Signal range 0—10 V

1 = Custom setting range from custom minimum (par. 2. 4) to custom maximum (par. 2. 5)

2.4 V_{in} custom setting minimum/maximum

2.5 These parameters set V_{in} for any input signal span within 0—10 V.

Minimum setting: Set the V_{in} signal to its minimum level, select parameter 2.4, press the Enter button

Maximum setting: Set the V_{in} signal to its maximum level, select parameter 2.5, press the Enter button

Note! The parameter values can only be set with this procedure (not with arrow up/ arrow down buttons).



2.6 V_{in} signal inversion

V_{in} is source B frequency reference,
par. 1.6 = 1 (default)

Parameter 2.6 = 0, no inversion
of analog V_{in} signal

Parameter 2.6 = 1, inversion
of analog V_{in} signal
max. V_{in} signal = minimum set
speed
min. V_{in} signal = maximum set
speed




Figure 3.5-5 V_{in} no signal inversion




Figure 3.5-6 V_{in} signal inversion.

2.7 V_{in} signal filter time

Filters out disturbances from the
incoming analog V_{in} signal. A
long filtering time makes drive
response slower. See figure 3.5-
7.




Figure 3.5-7 V_{in} signal filtering.

2.8 Analog input I_{in} signal range

- 0 = 0—20 mA
- 1 = 4—20 mA
- 2 = Custom signal span

See figure 3.5-8.

2.9 Analog input I_{in} custom setting minimum/maximum

2.10

With these parameters you can scale the input current to correspond to a minimum and maximum frequency range. See figure 3.5-8.

Minimum setting: Set the I_{in} signal to its minimum level, select parameter 2. 9, press the Enter button

Maximum setting:

Set the I_{in} signal to its maximum level, select parameter 2. 10, press the Enter button

Note! The parameter values can only be set with this procedure (not with arrow up/arrow down buttons).

2.11 Analog input I_{in} inversion

I_{in} is source A frequency reference, par. 1. 5 = 0 (default)

Parameter 2. 11 = 0, no inversion of I_{in} input

Parameter 2. 11 = 1, inversion of I_{in} input, see figure 3.5-9.

max. I_{in} signal = minimum set speed

min. I_{in} signal = maximum set speed

2.12 Analog input I_{in} filter time

Filters out disturbances from the incoming analog I_{in} signal. A long filtering time makes drive response slower. See figure 3.5-10.




Figure 3.5-8 Analog input I_{in} scaling.




Figure 3.5-9 I_{in} signal inversion.




Figure 3.5-10 Analog input I_{in} filter time.

2. 13, 2. 14 Reference scaling, minimum value/maximum value

Scales the basic reference.

Setting limits: par. 1. 1 < par. 2. 13 < par. 2. 14 < par. 1. 2.

If par. 2. 14 = 0 scaling is set off. See figures 3.5-11 and 3.5-12.




Figure 3.5-11 Reference scaling

Figure 3.5-12 Reference scaling,
par. 2. 14 = 0.

2. 18 Free analog input signal

Selection of input signal of free analog input (an input not used for reference signal):

- 0 = Not in use
- 1 = Voltage signal V_{in}
- 2 = Current signal I_{in}

2. 18 Free analog input signal function

Use this parameter to select a function for a free analog input signal:

- 0 = Function is not used
- 1 = Reducing motor current limit (par. 1. 7)

This signal will adjust the maximum motor current between 0 and the maximum set with parameter 1. 7.

See figure 3.5-13.




Figure 3.5-13 Reducing max. motor current.



2= Reducing DC brake current.

DC braking current can be reduced with the free analog input signal between current $0.15 \times I_{nSV9}$ and current set by the parameter 4. 8. See figure 3.5-14.




Figure 2.5-14 Reducing DC brake current.

3 = Reducing acceleration and deceleration times.

Acceleration/deceleration times can be reduced with a free analog input signal according to the following formulas:

Reduced time = set acc./deceler. time (par. 1. 3, 1. 4; 4. 3, 4. 4) divided by the factor R from the figure 3.5-15.




Figure 3.5-15 Reducing acceleration and deceleration times.

4 = Reducing torque supervision limit.

Torque supervision limit can be reduced with a free analog input signal between 0 and set supervision limit (par. 3. 14), see figure 3.5-16.




Figure 3.5-16 Reducing torque supervision limit.

3.1 Analog output function

See table for parameter 3.1 on page 3-9.

3.2 Analog output filter time

Filters the analog output signal.
See figure 3.5-17.

3.3 Analog output invert

Inverts analog output signal:
max. output signal = minimum
set value
min. output signal = maximum
set value

3.4 Analog output minimum

Defines the signal minimum to be
either 0 mA or 4 mA (living zero).
See figure 3.5-19.




Figure 3.5-17 Analog output filtering.




Figure 3.5-18 Analog output invert.

3.5 Analog output scale

Scaling factor for analog output.
See figure 3.5-19.

Signal	Max. value of the signal
Output frequency	Max. frequency (p. 1. 2)
Output current	$2 \times I_{nSV9}$
Motor speed	Max. speed ($n_{x\text{f}_{\text{max}}}/f_n$)
Motor torque	$2 \times T_{n\text{Mot}}$
Motor power	$2 \times P_{n\text{Mot}}$
Motor voltage	$100\% \times V_{n\text{Mot}}$
DC-link volt.	1000 V




Figure 3.5-19 Analog output scale.

3. 6 **Digital output function**
 3. 7 **Relay output 1 function**
 3. 8 **Relay output 2 function**

Setting value	Signal content
0 = Not used	Out of operation <u>Digital output DO1 sinks current and programmable relay (RO1, RO2) is activated when:</u>
1 = Ready	The drive is ready to operate
2 = Run	The drive operates (motor is running)
3 = Fault	A fault trip has occurred
4 = Fault inverted	A fault trip <u>has not</u> occurred
5 = SV9000 overheat warning	The heat-sink temperature exceeds +70°C
6 = External fault or warning	Fault or warning depending on parameter 7. 2
7 = Reference fault or warning	Fault or warning depending on parameter 7. 1 - if analog reference is 4—20 mA and signal is <4mA
8 = Warning	Always if a warning exists
9 = Reversed	The reverse command has been selected
10= Jog speed selected	The Jog speed has been selected with digital input
11= At speed	The output frequency has reached the set reference
12= Motor regulator activated	Overvoltage or overcurrent regulator was activated
13= Output frequency supervision 1	The output frequency goes outside of the set supervision Low limit/ High limit (par. 3. 9 and 3. 10)
14= Output frequency supervision 2	The output frequency goes outside of the set supervision Low limit/ High limit (par. 3. 11 and 3. 12)
15= Torque limit supervision	The motor torque goes outside of the set supervision Low limit/ High limit (par. 3. 13 and 3. 14)
16= Active reference	Active reference goes outside of the set supervision limit supervision Low limit/ High limit (par. 3. 15 and 3. 16)
17= External brake control	External brake ON/OFF control with programmable delay (par 3. 17 and 3. 18)
18= Control from I/O terminals	External control mode selected with prog. push-button#2
19= Drive temperature supervision	Temperature on drive goes outside the set supervision limits (par. 3. 19 and 3. 20)
20= Unrequested rotation direction	Rotation direction of the motor shaft is different from the requested one
21= External brake control inverted	External brake ON/OFF control (par 3.17 and 3.18), output active when brake control is OFF

Table 3.5-2 *Output signals via DO1 and output relays RO1 and RO2.*

3. 9 **Output frequency limit 1, supervision function**
 3. 11 **Output frequency limit 2, supervision function**

- 0 = No supervision
 1 = Low limit supervision
 2 = High limit supervision

If the output frequency goes under/over the set limit (3. 10, 3. 12) this function generates a warning message via the digital output DO1 or via a relay output RO1 or RO2 depending on the settings of the parameters 3. 6—3. 8.

3. 10 **Output frequency limit 1, supervision value**
 3. 12 **Output frequency limit 2, supervision value**

The frequency value to be supervised by the parameter 3. 9 (3. 11).
 See figure 3.5-20.



3. 13 Torque limit , supervision function

- 0 = No supervision
- 1 = Low limit supervision
- 2 = High limit supervision

If the calculated torque value goes under/over the set limit (3. 14) this function generates a warning message via the digital output DO1 or via a relay output RO1 or RO2 depending on the settings of the parameters 3. 6—3. 8.




Figure 3.5-20 Output frequency supervision.

3. 14 Torque limit , supervision value

The calculated torque value to be supervised by the parameter 3.13. Torque supervision value can be reduced below the setpoint with a free analog input signal, see parameters 2.18 and 2.19.

3. 15 Reference limit , supervision function

- 0 = No supervision
- 1 = Low limit supervision
- 2 = High limit supervision

If the reference value goes under/over the set limit (3. 16) this function generates a warning message via the digital output DO1 and via a relay output RO1 or RO2 depending on the settings of the parameters 3. 6—3. 8. The supervised reference is the current active reference. It can be the source A or B reference depending on DIB6 input or the panel reference if the panel is the active control source.

3. 16 Reference limit , supervision value

The frequency value to be supervised by the parameter 3. 15.

3. 17 External brake-off delay

3. 18 External brake-on delay

The function of the external brake can be delayed from the start and stop control signals with these parameters. See figure 3.5-21.

The brake control signal can be programmed via the digital output DO1 or via one of the relay outputs RO1 and RO2, see parameters 3. 6—3. 8.




Figure 3.5-21 External brake control:
a) Start/Stop logic selection par. 2. 1 = 0, 1 or 2
b) Start/Stop logic selection par. 2. 1 = 3.



3. 19 Drive temperature limit supervision

- 0 = No supervision
- 1 = Low limit supervision
- 2 = High limit supervision

If the temperature of the unit goes under/over the set limit (3. 20) this function generates a warning message via the digital output DO1 or via a relay output RO1 or RO2 depending on the settings of the parameters 3. 6—3. 8.

3. 20 Drive temperature limit value

The temperature value to be supervised by the parameter 3. 19.

4. 1 Acc/Dec ramp 1 shape

4. 2 Acc/Dec ramp 2 shape

The acceleration and deceleration ramp shape can be programmed with these parameters.

Setting the value = 0 gives you a linear ramp shape. The output frequency immediately follows the input with a ramp time set by parameters 1. 3, 1. 4 (4. 3, 4. 4 for Acc/Dec time 2).

Setting 0.1—10 seconds for 4. 1 (4. 2) causes an S-shaped ramp. The speed changes are smooth. Parameter 1. 3/ 1. 4 (4. 3/ 4. 4) determines the ramp time of the acceleration/deceleration in the middle of the curve. See figure 3.5-22.




Figure 3.5-22 S-shaped acceleration/deceleration

4. 3 Acceleration time 2

4. 4 Deceleration time 2

These values correspond to the time required for output frequency to accelerate from the set minimum frequency (par. 1. 1) to the set maximum frequency (par. 1. 2). With this parameter it is possible to set two different acceleration/deceleration times for one application. The active set can be selected with the programmable signal DIA3. See parameter 2. 2. Acceleration/deceleration times can be reduced with a free analog input signal. See parameters 2. 18 and 2. 19.

4.5 Brake chopper

- 0 = No brake chopper
- 1 = Brake chopper and brake resistor installed
- 2 = External brake chopper

When the drive is decelerating the motor, the energy stored in the inertia of the motor and the load is fed into the external brake resistor. If the brake resistor is selected correctly the drive is able to decelerate the load with a torque equal to that of acceleration. See the separate Brake resistor installation manual.

4.6 Start function

Ramp:

- 0 The drive starts from 0 Hz and accelerates to the set reference frequency within the set acceleration time. (Load inertia or starting friction may cause prolonged acceleration times).

Flying start:

- 1 The drive starts into a running motor by first finding the speed the motor is running at. Searching starts from the maximum frequency down until the actual frequency reached. The output frequency then accelerates/decelerates to the set reference value at a rate determined by the acceleration/deceleration ramp parameters.

Use this mode if the motor may be coasting when the start command is given. With the flying start it is possible to ride through short utility voltage interruptions.

4.7 Stop function

Coasting:

- 0 The motor coasts to an uncontrolled stop with the SV9000 off, after the Stop command.

Ramp:

- 1 After the Stop command, the speed of the motor is decelerated according to the deceleration ramp time parameter. If the regenerated energy is high it may be necessary to use an external braking resistor for faster deceleration.

4.8 DC braking current

Determines whether DC braking is ON or OFF. It also determines the braking duration time of the DC-brake when the motor is stopping. The function of the DC-brake depends on the stop function, parameter 4. 7. See figure 3.5-23.

- 0 DC-brake is not used
- >0 DC-brake is in use depending on the setup of the stop function (param. 4. 7). The time is set by the value of parameter 4. 9:

Stop-function = 0 (coasting):

After the stop command, the motor will coast to a stop with the SV9000 off.

With DC-injection, the motor can be electrically stopped in the shortest possible time, without using an optional external braking resistor.

The braking time is scaled according to the frequency when the DC- braking starts. If the frequency is \geq nominal frequency of the motor (par. 1.11), the value of parameter 4.9 determines the braking time. When the frequency is $\leq 10\%$ of the nominal, the braking time is 10% of the set value of parameter 4.9.

Stop-function = 1 (ramp):

After a Stop command, the speed of the motor is reduced based on the deceleration ramp parameter. If no regeneration occurs due to load inertia DC-braking starts at a speed defined by parameter 4. 10.




Figure 3.5-23 DC-braking time when stop = coasting.

The braking time is defined with parameter 4.9.

If a high inertia exists it is recommended to use an external braking resistor for faster deceleration. See figure 3.5-24.

4. 10

Execute frequency of DC-brake during ramp Stop

See figure 3.5-24.




Figure 3.5-24 DC-braking time when stop function = ramp.



4. 11 DC-brake time at start

- 0** DC-brake is not used
- >0** DC-brake is active when the start command is given. This parameter defines the time before the brake is released. After the brake is released, the output frequency increases according to the set start function parameter 4. 6 and the acceleration parameters (1.3, 4.1 or 4.2, 4.3). See figure 3.5-25.




Figure 3.5-25 DC-braking time at start

**5. 1- 5.6 Prohibit frequency area
Low limit/High limit**

In some systems it may be necessary to avoid certain frequencies because of mechanical resonance problems.

With these parameters it is possible to set limits for three "skip frequency" regions between 0 Hz and 500 Hz. The accuracy of the setting is 0.1 Hz. See figure 3.5-26.




Figure 3.5-26 Example of prohibit frequency area setting.

6. 1 Motor control mode

0 = Frequency control: The I/O terminal and panel references are frequency (V/Hz) references and the drive controls the output frequency (output freq. resolution 0.01 Hz)

1 = Speed control: The I/O terminal and panel references are speed references (sensorless vector) and the drive controls the motor speed (control accuracy $\pm 0.5\%$).

6. 2 Switching frequency

Motor noise can be minimized by using a high switching frequency. Increasing the switching frequency reduces the current capacity of the SV9000.

Before changing the frequency from the factory default 10 kHz (3.6 kHz >40 Hp) check the drive derating in the curves shown in figures 5.2-2 and 5.2-3 in chapter 5.2 of the User's Manual.

6. 3 Field weakening point**6. 4 Voltage at the field weakening point**

The field weakening point is the output frequency where the output voltage reaches the set maximum value. Above that frequency the output voltage remains at the set maximum value.

Below that frequency output voltage depends on the setting of the V/Hz curve parameters 1. 8, 1. 9, 6. 5, 6. 6 and 6. 7. See figure 3.5-27.

When the parameters 1. 10 and 1. 11, nominal voltage and nominal frequency of the motor are set, parameters 6. 3 and 6. 4 are also set automatically to the corresponding values. If you need different values for the field weakening point and the maximum output voltage, change these parameters after setting parameters 1. 10 and 1. 11.

6. 5 V/Hz curve, middle point frequency

If the programmable V/Hz curve has been selected with parameter 1. 8, this parameter defines the middle frequency point of the curve. See figure 3.5-27.

6. 6 V/Hz curve, middle point voltage

If the programmable V/Hz curve has been selected with parameter 1. 8, this parameter defines the middle point voltage (% of motor nominal voltage) of the curve. See figure 3.5-27.

6. 7 Output voltage at zero frequency

If the programmable V/Hz curve has been selected with parameter 1. 8, this parameter defines the zero frequency voltage of the curve. See figure 3.5-27.






Figure 3.5-27 Programmable V/Hz curve.

6.8 Overvoltage controller

6.9 Undervoltage controller

These parameters allow the over/undervoltage controllers to be switched ON or OFF. This may be useful in cases where the utility supply voltage varies more than -15%—+10% and the application requires a constant speed. If the controllers are ON, they will change the motor speed in over/undervoltage cases. Overvoltage = faster, undervoltage = slower.

Over/undervoltage trips may occur when controllers are not used.

7.1 Response to the reference fault

- 0 = No response
- 1 = Warning
- 2 = Fault, stop mode after fault according to parameter 4.7
- 3 = Fault, always coasting stop mode after fault

A warning or a fault action and message is generated if the 4—20 mA reference signal is used and the signal falls below 4 mA. The information can also be programmed via digital output DO1 and via relay outputs RO1 and RO2.

7.2 Response to external fault

- 0 = No response
- 1 = Warning
- 2 = Fault, stop mode after fault according to parameter 4.7
- 3 = Fault, stop mode after fault always by coasting

A warning or a fault action and message is generated from the external fault signal in the digital input DIA3. The information can also be programmed into digital output DO1 and into relay outputs RO1 and RO2.

7.3 Phase supervision of the motor

- 0 = No action
- 2 = Fault

Phase supervision of the motor ensures that the motor phases have approximately equal current.

7.4 Ground fault protection

- 0 = No action
- 2 = Fault

Ground fault protection ensures that the sum of the motor phase currents is zero. The standard overcurrent protection is always working and protects the frequency converter from ground faults with high current levels.

Parameters 7.5—7.9 Motor thermal protection

General

Motor thermal protection is to protect the motor from overheating. The SV9000 drive is capable of supplying higher than nominal current to the motor. If the load requires this high current there is a risk that motor will be thermally overloaded. This is true especially at low frequencies. With low frequencies the cooling effect of the motor fan is reduced and the capacity of the motor is reduced. If the motor is equipped with a separately powered external fan, the load derating at low speed is small.

Motor thermal protection is based on a calculated model and it uses the output current of the drive to determine the load on the motor. When the motor is powered from the drive, the calculated model uses the heatsink temperature to determine the initial thermal state of the motor. The calculated model assumes that the ambient temperature of the motor is 40°C.

Motor thermal protection can be adjusted by setting several parameters. The thermal current I_T specifies the load current above which the motor is overloaded. This current limit is a function of the output frequency. The curve for I_T is set with parameters 7.6, 7.7 and 7.9, refer to the figure 3.5-28. The default values of these parameters are set from the motor nameplate data.

With the output current at I_T the thermal stage will reach the nominal value (100%). The thermal stage changes with the square of the current. With output current at 75% of I_T the thermal stage will reach 56% and with output current at 120% of I_T the thermal stage would reach 144%. The function will trip the drive (refer par. 7.5) if the thermal state reaches a value of 105%. The response time of the thermal stage is determined by the time constant parameter 7.8. The larger the motor, the longer it takes to reach the final temperature.

The thermal state of the motor can be monitored through the display. Refer to the table for monitoring items. (User's Manual, table 7.3-1).



CAUTION! *The calculated model does not protect the motor if the cooling of the motor is reduced either by blocking the airflow or due to dust or dirt.*

7.5 Motor thermal protection

Operation:

- 0 = Not in use
- 1 = Warning
- 2 = Trip function

Tripping and warning will give a display indication with the same message code. If tripping is selected, the drive will stop and activate the fault stage.



Deactivating the stall protection by setting the parameter to 0 will reset the stall time counter to zero.

7.6 Motor thermal protection, break point current

The current can be set between 50.0—150.0% $\times I_{nMotor}$.

This parameter sets the value for thermal current at frequencies above the break point on the thermal current curve. See figure 3.5-28.

The value is set as a percentage of the motor nameplate nominal current, parameter 1. 13, not the drive's nominal output current.

The motor's nominal current is the current which the motor can withstand in direct on-line use without being overheated.

If parameter 1. 13 is adjusted, this parameter is automatically restored to the default value.

Setting this parameter (or parameter 1.13) does not affect the maximum output current of the drive. Parameter 1. 7 alone determines the maximum output current of the drive.




Figure 3.5-28 Motor thermal current I_T curve.

7.7 Motor thermal protection, zero frequency current

The current can be set between 10.0—150.0% $\times I_{nMotor}$.

This parameter sets the value for thermal current at zero frequency. Refer to figure 3.5-28.

The default value is set assuming that there is no external fan cooling the motor. If an external fan is used this parameter can be set to 90% (or higher).

The value is set as a percentage of the motor's nameplate nominal current, parameter 1. 13, not the drive's nominal output current. The motor's nominal current is the current which the motor can stand in direct on-line use without being overheated. If you change parameter 1. 13, this parameter is automatically restored to the default value.

Setting this parameter (or parameter 1. 13) does not affect to the maximum output current of the drive. Parameter 1. 7 alone determines the maximum output current of the drive.

7.8 Motor thermal protection, time constant

This time can be set between 0.5—300 minutes. This is the thermal time constant of the motor. The larger the motor the greater the time constant. The time constant is defined as the time that it takes the calculated thermal stage to reach 63% of its final value.

The motor thermal time is specific to a motor design and it varies between different motor manufacturers.

The default value for the time constant is calculated based on the motor nameplate data from parameters 1.12 and 1.13. If either of these parameters is reset, then this parameter is set to default value.

If the motor's t_6 -time is known (given by the motor manufacturer) the time constant parameter could be set based on t_6 -time. As a rule of thumb, the motor thermal time constant in minutes equals to $2 \times t_6$ (t_6 in seconds is the time a motor can safely operate at six times the rated current). If the drive is stopped the time constant is internally increased to three times the set parameter value. Cooling in the stop stage is based on convection with an increased time constant.

7.9 Motor thermal protection, break point frequency

The frequency can be set between 10—500 Hz. This is the frequency break point of the thermal current curve. With frequencies above this point, the thermal capacity of the motor is assumed to be constant. See figure 3.5-28.

The default value is based on the motor's nameplate data, parameter 1. 11. It is 35 Hz for a 50 Hz motor and 42 Hz for a 60 Hz motor. More generally it is 70% of the frequency at the field weakening point (parameter 6. 3). Changing either parameter 1. 11 or 6. 3 will restore this parameter to its default value.

7.10 Stall protection

Operation:

- 0 = Not in use
- 1 = Warning
- 2 = Trip function

Tripping and warning will give a display indication with the same message code. If tripping is set on, the drive will stop and activate the fault stage. Setting the parameter to 0 will deactivate the protection and will reset the stall time counter to zero.




Figure 3.5-29 Calculating motor temperature.



Parameters 7. 10— 7. 13, Stall protection

General

Motor stall protection protects the motor from short time overload situations like a stalled shaft. The reaction time of stall protection can be set shorter than with motor thermal protection. The stall state is defined with two parameters, 7.11. Stall Current and 7.13. Stall Frequency. If the current is higher than the set limit and output frequency is lower than the set limit the stall state is true. There is actually no real indication of the shaft rotation. Stall protection is a type of overcurrent protection.

7. 11 Stall current limit

The current can be set between 0.0—200% $\times I_{nMotor}$.

In a stall the current has to be above this limit. See figure 3.5-30. The value is set as a percentage of the motor's nameplate nominal current, parameter 1. 13. If parameter 1. 13 is adjusted, this parameter is automatically restored to its default value.

7. 12 Stall time

The time can be set between 2.0—120 s. This is the maximum allowed time for a stall. There is an internal up/down counter to count the stall time. See figure 3.5-31. If the stall time counter value goes above this limit the protection will cause a trip (refer to parameter 7. 10).

7. 13 Maximum stall frequency

The frequency can be set between 1— f_{max} (parameter 1. 2).

In a stall, the output frequency has to be smaller than this limit. See figure 3.5-30.




Figure 3.5-30 Setting the stall characteristics.

Parameters 7. 14— 7. 17

Underload protection, General

The purpose of motor underload protection is to ensure that there is load on the motor while the drive is running. If the motor load is reduced, there might be a problem in the process, e.g. broken belt or dry pump.

Motor underload protection can be adjusted by setting the underload curve with parameters 7. 15 and 7. 16. The underload curve is a squared curve set between zero frequency and the




Figure 3.5-31 Counting the stall time.

field weakening point. The protection is not active below 5Hz (the underload counter value is stopped). See figure 3.5-32.

The torque values for setting the underload curve are set with percentage values which refer to the nominal torque of the motor. The motor's nameplate data, parameter 1. 13, the motor's nominal current and drive's nominal current I_{CT} are used to find the scaling ratio for the internal torque value. If other than a standard motor is used with the drive, the accuracy of the torque calculation is decreased.

7. 14 Underload protection

Operation:

- 0 = Not in use
- 1 = Warning
- 2 = Fault

Tripping and warning will give a display indication with the same message code. If tripping is set active the drive will stop and activate the fault stage.

Deactivating the protection, by setting this parameter to 0, will reset the underload time counter to zero.

7. 15 Underload protection, field weakening area load

The torque limit can be set between 20.0—150 % x T_{nMotor} .

This parameter is the value for the minimum allowed torque when the output frequency is above the field weakening point. See figure 3.5-32. If parameter 1. 13 is adjusted, this parameter is automatically restored to its default value.

7. 16 Underload protection, zero frequency load

The torque limit can be set between 10.0—150 % x T_{nMotor} .

This parameter is the value for the minimum allowed torque with zero frequency. Refer to the figure 3.5-32. If parameter 1. 13 is adjusted this parameter is automatically restored to its default value.

7. 17 Underload time

This time can be set between 2.0—600.0 s.

This is the maximum allowed time for an underload state. There is an internal up/down counter to accumulate the underload time. Refer to the figure 3.5-33. If the underload counter value goes above this limit, the protection will cause a trip (refer to the parameter 7. 14). If the drive is stopped, the underload counter is reset to zero.




Figure 3.5-32 Setting of minimum load.




Figure 3.5-33 Counting the underload time.



8.1 Automatic restart: number of tries**8.2 Automatic restart: trial time**

The Automatic restart function restarts the drive after the faults selected with parameters 8.4 - 8.8. The Start function for Automatic restart is selected with parameter 8.3. See figure 3.5-34.




Figure 3.5-34 Automatic restart.

Parameter 8.1 determines how many automatic restarts can be made during the trial time set by the parameter 8.2.

The time counting starts from the first autorestart. If the number of restarts does not exceed the value of the parameter 8.1 during the trial time, the count is cleared after the trial time has elapsed. The next fault starts the counting again.

8.3 Automatic restart, start function

The parameter defines the start mode:

- 0 = Start with ramp
- 1 = Flying start, see parameter 4.6.

8.4 Automatic restart after undervoltage trip

- 0 = No automatic restart after undervoltage fault
- 1 = Automatic restart after undervoltage fault condition returns to the normal condition (DC-link voltage returns to the normal level)

8.5 Automatic restart after overvoltage trip

- 0 = No automatic restart after overvoltage fault
- 1 = Automatic restart after overvoltage fault condition returns to the normal condition (DC-link voltage returns to the normal level)

8.6 Automatic restart after overcurrent trip

- 0 = No automatic restart after overcurrent fault
- 1 = Automatic restart after overcurrent faults



8.7 Automatic restart after reference fault trip

0 = No automatic restart after reference fault

1 = Automatic restart after analog current reference signal (4—20 mA) returns to the normal level (≥ 4 mA)

8.8 Automatic restart after over-/undertemperature fault trip

0 = No automatic restart after temperature fault

1 = Automatic restart after heatsink temperature has returned to its normal level between -10°C—+75°C.

Notes:

3



Cutler-Hammer, a part of Eaton Corporation, is a worldwide leader providing customer-driven solutions. From power distribution and electrical control products to industrial automation, Cutler-Hammer utilizes advanced product development, world-class manufacturing, and offers global engineering services and support.

For more information on Cutler-Hammer products, call 1-800-525-2000 or 1-616-982-1059, for engineering services call 1-800-498-2678, or visit our web site at www.cutlerhammer.eaton.com

For Cutler-Hammer Adjustable Frequency Drives technical information and support, please call 1-800-322-4986.



TD.08H.12.T.E

Cutler-Hammer

Milwaukee, Wisconsin U.S.A.

Publication No. TD.08H.12.T.E
March 1999
Printed in U.S.A.

Copyright Cutler-Hammer Inc., 1999
All Rights Reserved

The Eaton logo, featuring the word "EATON" in a bold, sans-serif font. The letter "A" is stylized with a dot in the center.