



CAUTION


Care should be taken when tightening the nuts. The fasteners must be tightened enough to obtain a proper seal, but not over tightened to the point where the threads are stripped or the gasket is rendered useless. Always use a torque wrench when installing your PanelMate unit.



CAUTION

The reproduction process may distort this cutout template. Always check your dimensions prior to cutting your panel.

Torque Limits for Studs
5 inch-pounds for #6-32 nuts



Cutout Template

Notes:
Dimensions are in inches.
Millimeter dimensions are in parentheses.